

USING THE PROJECTION STATION

1. ON / OFF BUTTONS

Make sure the display is ON, otherwise, you won't see anything on the screen.

When you press OFF, the projector will start to shut down. When the OFF switch is blinking, the projector is not ready to turn back on again. The shutdown process takes a while, so don't press OFF unless you really mean it.

2. INPUT SELECTORS

Input 1: VCR. Displays VCR image. The VCR is inside the black case.

Input 2: DVI Cable. For laptops. Connect your laptop to the white connector and its accompanying sound cable.

Input 3: S-VIDEO. Coming soon.

Input 4: DVD. Turns on DVD image.

Input 5: PC. Connected to the dual-imaged Mac at the end of the lab table (see photo).

Input 6: LAPTOP. The blue-ended connector for most laptops; has accompanying sound cable.

3. DVD & VCR CONTROLS

Use these to control the DVD and VCR playback. You don't have to touch anything inside the box.



4. MASTER VOLUME


Controls the speakers. Start from a low volume and work upwards.

5. MISCELLANEOUS

A/V Mute: Cuts signal from both audio and video.

PIP: Picture In Picture: also known as Split Screen (oohh!).

Auto Image: NEVER TOUCH, EVER.



**IF IT STILL DOESN'T WORK,
ASK THE CONSULTANT!**